

**Настройка префикс STX на Metrologic MS9540 Voyager CG**

**Recall Defaults**



Enter

**Enter/Exit Configuration Mode**



Configurable Prefix Character 1



0



0



2



Exit

**Enter/Exit Configuration Mode**

